

Battery Terminal Fuse

RoHS

ELV

BATF-I

5回路用



Battery Terminal Fuse

RoHS

ELV

BATF-L

2回路用



Battery Terminal Fuse

RoHS

ELV

BATF-M

5回路用



Battery Terminal Fuse

RoHS

ELV

BATF-N

6回路用



BATF