

Battery Terminal Fuse

RoHS

ELV

# BATF-I

5回路用



Battery Terminal Fuse

RoHS

ELV

# BATF-L

2回路用



Battery Terminal Fuse

RoHS

ELV

# BATF-M

5回路用



Battery Terminal Fuse

RoHS

ELV

# BATF-N

6回路用



BATF